

§ 135.93 Autopilot: Minimum altitudes for use.

(a) Except as provided in paragraphs (b), (c), (d), and (e) of this section, no person may use an autopilot at an altitude above the terrain which is less than 500 feet or less than twice the maximum altitude loss specified in the approved Aircraft Flight Manual or equivalent for a malfunction of the autopilot, whichever is higher.

(b) When using an instrument approach facility other than ILS, no person may use an autopilot at an altitude above the terrain that is less than 50 feet below the approved minimum descent altitude for that procedure, or less than twice the maximum loss specified in the approved Airplane Flight Manual or equivalent for a malfunction of the autopilot under approach conditions, whichever is higher.

(c) For ILS approaches, when reported weather conditions are less than the basic weather conditions in §91.155 of this chapter, no person may use an autopilot with an approach coupler at an altitude above the terrain that is less than 50 feet above the terrain, or the maximum altitude loss specified in the approved Airplane Flight Manual or equivalent for the malfunction of the autopilot with approach coupler, whichever is higher.

(d) Without regard to paragraph (a), (b), or (c) of this section, the Administrator may issue operations specifications to allow the use, to touchdown, of an approved flight control guidance system with automatic capability, if—

(1) The system does not contain any altitude loss (above zero) specified in the approved Aircraft Flight Manual or equivalent for malfunction of the autopilot with approach coupler; and

(2) The Administrator finds that the use of the system to touchdown will not otherwise adversely affect the safety standards of this section.

(e) Notwithstanding paragraph (a) of this section, the Administrator issues operations specifications to allow the use of an approved autopilot system with automatic capability during the takeoff and initial climb phase of flight provided:

(1) The Airplane Flight Manual specifies a minimum altitude engagement certification restriction;

(2) The system is not engaged prior to the minimum engagement certification restriction specified in the Airplane Flight Manual, or an altitude specified by the Administrator, whichever is higher; and

(3) The Administrator finds that the use of the system will not otherwise affect the safety standards required by this section.

(f) This section does not apply to operations conducted in rotorcraft.

[Doc. No. 16097, 43 FR 46783, Oct. 10, 1978, as amended by Amdt. 135-32, 54 FR 34332, Aug. 18, 1989; Amdt. 135-68, 62 FR 27923, May 21, 1997]

§ 135.95 Airmen: Limitations on use of services.

No certificate holder may use the services of any person as an airman unless the person performing those services—

(a) Holds an appropriate and current airman certificate; and

(b) Is qualified, under this chapter, for the operation for which the person is to be used.

§ 135.97 Aircraft and facilities for recent flight experience.

Each certificate holder shall provide aircraft and facilities to enable each of its pilots to maintain and demonstrate the pilot's ability to conduct all operations for which the pilot is authorized.

§ 135.99 Composition of flight crew.

(a) No certificate holder may operate an aircraft with less than the minimum flight crew specified in the aircraft operating limitations or the Aircraft Flight Manual for that aircraft and required by this part for the kind of operation being conducted.

(b) No certificate holder may operate an aircraft without a second in command if that aircraft has a passenger seating configuration, excluding any pilot seat, of ten seats or more.

§ 135.100 Flight crewmember duties.

(a) No certificate holder shall require, nor may any flight crewmember perform, any duties during a critical phase of flight except those duties required for the safe operation of the aircraft. Duties such as company required